

## Wheel Loader Front or Rear Sliding Couplers





From the operators cab, power the coupler left or right, release the coupler pin and control the railcar brakes.



For non-hi-rail applications the front or rear mount Railcar Coupler makes a good choice. The coupler can be free float left or right in the manual alignment bumper. The coupler can be mounted on the front through a quick coupler or permanently mounted on the rear frame of the machine.

The 42 inch front coupler has a total travel of 18 inches and the rear 82 inch coupler has a total travel of 58 inches.

Each system is specially configured to fit each wheel loader.

To control the railcar brakes a 24 cfm hydraulic driven train air brake system can be added that allows the operator to safely start and stop the train.

## Cab controlled Hydraulic Pin Lift.

