



Tie Head Attachment with Scarifer Blade



The Tie Head with its continuous rotation can quickly position itself over a tie to remove it from under the rail. The built-in Scarifier blade can be rotated 90 degrees to remove ballast and the end of the tie to create an opening for the tie to come out. The tie head can position itself where ever a new tie might be laying along side the track to quickly insert the tie under the rail. The tie head jaws grab on the end of the tie and the jaws are the right length to position the tie just right without any adjustment. The Scarifier blade then can replace the ballast at the end of the tie. For broken or rotten ties the Scarifier blade can easily dig the ties out.

Replace a Tie in under 2 minutes with no damage to the new tie

www.Mitchell-RailGear.com

5275 N. Ann Arbor Rd. Dundee, MI 48131 USA Tel: 734-529-3433 Fax: 734-529-3433